

Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

An optional larger tool kit may be available. Check with your Honda dealer’s parts department.

Importance of Maintenance	P. 139	Final Drive Oil	P. 163	Other Replacement	P. 174
Maintenance Schedule	P. 140	Brakes	P. 164	Honda SMART Key Battery.....	P. 174
Maintenance Fundamentals	P. 143	Side Stand	P. 167		
Removing & Installing Body Components .	P. 153	Clutch	P. 168		
Battery	P. 153	Throttle	P. 169		
Cylinder Head Side Cover	P. 154	Crankcase Breather	P. 170		
Fog Light Cover.....	P. 155	Other Adjustments	P. 171		
Left Engine Side Cover	P. 155	Headlight Aim	P. 171		
Side Cover.....	P. 156	Clutch and Brake Levers	P. 171		
Spark Plug	P. 157	Electrical Adjustable Suspension			
Engine Oil	P. 158	GL1800/D/DA	P. 172		
Coolant	P. 162	Rear Suspension GL1800B/BD	P. 173		