

After removing your motorcycle from storage, inspect all maintenance items required by the Maintenance Schedule.

**USA** For more information about storage, refer to the *Honda Winter Storage Guide*, available from your dealer.

**Canada** For more information about storage, visit our website at [www.honda.ca](http://www.honda.ca) and look up “Storage Tips” under the “Honda Warranty” in the Warranty tab for your Model.

## Transporting Your Motorcycle

If your motorcycle needs to be transported, it should be carried on a motorcycle trailer or a flatbed truck or trailer that has a loading ramp or lifting platform, and motorcycle tie-down straps. Never try to tow your motorcycle with a wheel or wheels on the ground.

### NOTICE

- Towing your motorcycle can cause serious damage to the transmission.
- When tying down the motorcycle for transportation, do not use tie-downs or straps on the handlebars or handgrips. Doing so may cause damage to the steering system, heated grips and/or handlebar switches.

### Tie-down Method

1. Remove both sides of the cylinder head side covers. ➤ P. 154
2. Secure the motorcycle using a buckle or ratchet style tie-down strap to the engine guards and affix the other ends to an anchor point.
  - ▶ Make sure the tie-downs straps are tight and the motorcycle is secure.

