

## **⚠ WARNING**

Never use petrol or low flash point solvents to clean the air cleaner element. A fire or explosion could result.

Soak the element in a special air cleaner or engine oil and drain out the excess.

## **NOTICE**

Do not twist the element to squeeze out the excess oil. Failure to follow this precaution can result in a damaged element.

Installation is in the reverse order of removal.

