

Adjusting the throttle free play

Adjustment is made with the throttle cable adjuster.

1. Slide the rubber dust cover off from the cable adjuster.
2. Loosen the lock nut.
3. Turn the adjuster.
 - ▶ Turn the adjuster towards "A" to reduce the free play.
 - ▶ Turn the adjuster towards "B" to increase the free play.
4. Tighten the lock nut after adjustment.

Operate the throttle grip to ensure that it functions smoothly and returns completely in all steering positions.

