





Items		Frequency*1								Refer to page	
		x 1,000 mi	0.6	2.5	5	7.5	10	12.5	15		
		x 1,000 km	1	4	8	12	16	20	24		
Non-Emission-Related Items	DRIVE CHAIN		Every 300 mi (500 km): I L							65	
	BRAKE FLUID *4			I	I	I	I	I	I	61	
	BRAKE PADS WEAR			I	I	I	I	I	I	62	
	BRAKE SYSTEM		I	I	I	I	I	I	I	40	
	BRAKE LIGHT SWITCH			I	I	I	I	I	I	63	
	HEADLIGHT AIM			I	I	I	I	I	I	73	
	CLUTCH SYSTEM		I	I	I	I	I	I	I	68	
	SIDE STAND			I	I	I	I	I	I	64	
	SUSPENSION				I	I	I	I	I	I	-
	NUTS, BOLTS, FASTENERS			I		I		I		I	-
	WHEELS/TIRES				I	I	I	I	I	I	-
STEERING HEAD BEARINGS			I			I			I	-	

Maintenance Legend

- I** : Inspect (clean, adjust, lubricate, or replace, if necessary)
- C** : Clean
- L** : Lubricate
- R** : Replace

Notes:

- *1 : At higher odometer readings, repeat at the frequency interval established here.
- *2 : Service more frequently when riding in unusually wet or dusty areas.
- *3 : Service more frequently when riding in rain or at full throttle.
- *4 : Replace every 2 years. Replacement requires mechanical skill.