

Servicing Your Honda

To help keep your Honda MUV in good shape, this section includes a Maintenance Schedule for required service and step-by-step instructions for specific maintenance tasks. You'll also find important safety precautions, information on fuels and oils, and tips for keeping your Honda looking good.

For information about replacing fuses, see page 184.

(USA & Canada only)

For information about the exhaust emission and noise requirements of the U.S. Environmental Protection Agency (EPA), the California Air Resources Board (CARB), and Environment Canada (EC), see page 202.

USA Only

Maintenance, replacement or repair of the emission control devices and systems may be performed by any off-road utility vehicle repair establishment or individual using parts that are “certified” to EPA standards.

Before You Service Your Honda

| | |
|-------------------------------------|----|
| The Importance of Maintenance | 75 |
| Maintenance Safety..... | 76 |
| Important Safety Precautions..... | 77 |
| Maintenance Schedule | 78 |
| Maintenance Record | 82 |

Service Preparations

| | |
|---------------------------------------|----|
| Maintenance Component Locations | 83 |
| Tool Kit | 88 |
| Owner's Manual Storage..... | 89 |
| Front Hood | 90 |
| Seat Removal | 91 |
| Jack Up Point & Support Point..... | 92 |

(cont'd)