

# Quick Reference

---

These symbols are used in Driver Controls section:

SYMBOL	COMPONENT	SEE PAGE
II	START — ignition switch	25
I	ON — ignition switch	25
O	OFF — ignition switch	25
OFF	OFF — headlight switch	26
☰D	HI — headlight switch	26
☷D	LO — headlight switch	26
D, N, R	Drive — Neutral — Reverse — shift lever	27