



⇒ **Right turn signal indicator**

**N Neutral indicator**  
Comes on when the transmission is in Neutral.

☰ **High beam indicator**

⇐ **Left turn signal indicator**