

Stop Switch.....	34, 37, 38, 131
Stopping.....	40, 131
Environment.....	137
Equipment	
Owner's Manual	52
Tool Kit.....	52
F	
Flooded Engine.....	38, 39
Fuel	
Gauge.....	25, 26
Oxygenated	145
Recommended.....	49
Remaining.....	25, 26
Tank Capacity	49
Fuses	65, 127
G	
Gasohol.....	145
Gasoline.....	49
Gear Position Indicator.....	27
Gear shift operation	47

H	
Hazard Switch.....	34, 36
Headlight Aim	105
Headlight Dimmer Switch.....	34, 36
Helmet Holder	53
High Beam Indicator	33
High Coolant Temperature	
Indicator	32, 110
Honda Contacts.....	149
Horn Button.....	34, 37
I	
Ignition Cut-off System	
Banking Sensor.....	132
Side Stand	93
Ignition Key	130
Ignition Switch	35, 37, 131
Indicators	32
Information Record.....	155
Instruments.....	20
L	
Labels	7