<b>Periodic Checks</b> You should also perform other periodic maintenance checks at least once a month regardless of how often you ride, or more often if you ride frequently.		Also, check the odometer reading against the Maintenance Schedule and perform all maintenance that is due. ➡ P. 77
Tires and wheels	Check the air pressure (≥ P. 90), examine tread for wear and damage (≥ P. 90), and check the wheels for damage.	
Fluid levels	Check the engine oil level ( $\blacktriangleright$ P. 103), engine coolant level ( $\triangleright$ P. 109), and brake fluid level ( $\triangleright$ P. 111).	
Lights	Check that the headlight, position lights, brake light, taillight, license plate light and turn signals are working properly.	
Controls	Check the freeplay of the clutch lever (NC750X/XA) (⇒ P. 119) and throttle grip (⇒ P. 122), Check the front brake lever (⇒ P. 126), rear brake pedal and parking brake (NC750XD) (⇒ P. 113) operate properly.	
Drive chain	Check the slack ( $\triangleright$ P. 115), adjust the slack ( $\triangleright$ P. 116), and lubricate ( $\triangleright$ P. 88) as needed.	
Fuses	Check that you have a full supply of spare fuses.	
Nuts & bolts	Check the major nuts and bolts, and tighten as needed.	