

Index

engine,	
number	262
oil	148
pinging	145
starting	98
stopping	98
sub-transmission	161
won't start	236
environment	231

F

final gear oil	165, 167
flat tire	243
frame	195
fuel,	
fill cap	146
oxygenated	275
recommendation	145
tank capacity	146
fuses	248

G

gap, spark plug	185, 266
gasohol	275
gasoline	145
gear position indicator	36

H

headlight switch	41
hill start assist (HSA)	50