

# Index

---

sub-transmission .....	161
suspension,	
adjustment .....	190
damping, front .....	193
damping, rear .....	194
spring pre-load .....	191
switch,	
headlight .....	41
hill start assist (HSA) .....	50
ignition .....	40

## T

tailgate levers .....	79
tires,	
air pressure .....	203
flat .....	243
repairing .....	207
replacing .....	208
thread conditions .....	205, 206
tool kit .....	135
trailer hitch .....	83
trailer towing,	
operational guidelines .....	95
weight limits .....	95
transporting your Honda .....	226
tripmeter .....	30
trouble, unexpected .....	233
troubleshooting, starting .....	236
turning, on level ground .....	112

## V

vehicle identification no. (VIN) .....	262
--	-----