

Servicing Your Honda

Clip Removal	124
Jack Up Point & Support Point	125

Service Procedures

Fluids, Filters & Lubricants

Fuel	126
Engine Oil & Filters	129
Sub-Transmission Oil	142
Front Final Gear Oil.....	146
Rear Final Gear Oil.....	148
Coolant	151
Air Cleaner	156
Lubrication	161

Engine

Accelerator Pedal.....	164
Spark Plugs.....	166
Spark Arrester	169
Exhaust System.....	171

Chassis

Suspension	172
Brakes	176
Tires	182
Wheels	190
Driveshaft Boots	191

Electrical

Battery	192
Appearance Care.....	197