If you do not have a replacement fuse with the proper rating for the circuit, install one with a lower rating.

## NOTICE

Replacing a fuse with one that has a higher rating greatly increases the chance of damage to the electrical system.

6. Install the fuse holder assembly and seat.