

Quick Reference

| | |
|-------------------------|---|
| Scheduled Maintenance | Initial: 100 miles (150 km) Regular: every 600 miles (1,000 km) |
| Pre-ride Inspection | Check the following items each time before you ride (page 31): engine oil, fuel, tires, guards, nuts & bolts, underbody & exhaust system, air cleaner housing drain tube, leaks, loose parts, cables, lights, throttle, brakes, reverse assist lever, clutch lever/parking brake lever, switches, steering. |
| Fuel/Capacity | unleaded gasoline, pump octane number 86 or higher 2.51 US gal (9.5 l) reserve: 0.69 US gal (2.6 l) |
| Engine Oil/ Capacity | API Service Classification SG or higher except oils labeled as energy conserving or resource conserving on the circular API service label, SAE 10W-30, JASO T 903 standard MA, Pro Honda GN4 4-stroke oil or equivalent after draining: 1.6 US qt (1.5 l) |
| Maximum Weight Capacity | 243 lb (110 kg) rider, all cargo and accessories |