

# Index

---

## I

identification, vehicle .....	230
ignition switch .....	34
indicators,	
4WD indicator .....	14, 18, 23
gear position indicator .....	24
high coolant temperature indicator .....	14, 17, 218
maintenance minder indicator .....	32
neutral indicator .....	14, 17
PGM-FI indicator .....	14, 17
PS (Electric Power Steering) indicator (TRX420FA6 only) .....	14, 17
reverse indicator .....	14, 17
inspection, pre-ride .....	55

## K

key,	
lost .....	226
number .....	226
kit, tool .....	116

## L

labels, safety .....	5
lamp check .....	15
lever,	
2WD/4WD select .....	35
P/R .....	43
limit, weight .....	60
load limits .....	60
loading guidelines .....	61
lubrication,	
engine oil .....	126
front final gear oil .....	137
rear final gear oil .....	134