Starting & Stopping the Engine

Always follow the proper starting procedure described below.

For your safety, avoid starting or operating the engine in an enclosed area such as a garage. Your ATV's exhaust contains poisonous carbon monoxide gas which can collect rapidly in an enclosed area and cause illness or death.

When you stop riding in reverse and turn the ignition switch to the OFF \bigcirc) position

After the engine stops, turn the ignition switch to the ON ($\,$ $\,$ $\,$) position. The transmission is shifted in neutral automatically.

The starter motor will operate when the transmission is in neutral or the front brake lever is pulled in.