If Your Engine Quits or Won't Start

SYMPTOM: Engine starts, but runs poorly.	
POSSIBLE CAUSE	WHAT TO DO
high coolant	Check the high coolant temperature
temperature	indicator. Refer to If the High
	Coolant Temperature Indicator
	Lights, page198.
runs erratically,	See your dealer.
misfires	
blubbers (rich fuel mixture)	See your dealer.
sooty exhaust (rich	See your dealer.
fuel mixture)	
detonates or pings	If applicable, switch to the
under load	recommended octane gasoline
	(page 108) or change your brand of
	gasoline. If the problem persists, see
	your dealer.
afterfires (backfires)	See your dealer.
pre-ignition (runs on	See your dealer.
after ignition	
switched OFF)	

SYMPTOM: Engine starts, but runs poorly or dies when hot.	
POSSIBLE CAUSE	WHAT TO DO
poor or inadequate fuel flow due to clogged fuel filter	See your dealer. (ensure clean fuel supply)