
## **Drivetrain Boots**

## **Propeller Shaft Boots & Yoke Joint Boot**

Refer to Safety Precautions on page 89.



- (1) rubber propeller shaft boots (Except TRX420TE)
- (2) rubber yoke joint boot

Check the rubber propeller shaft boots (1) and rubber yoke joint boot (2) for damage or leaking grease. If necessary, have your dealer replace them.