

# Storing Your Honda

---

## Removal from Storage

Refer to *Safety Precautions* on [page 103](#).

1. Uncover and clean your ATV.
2. If your ATV has been stored for more than four months — change the engine oil ([page 127](#)).
3. If your ATV has been stored for more than two months — ask your dealer to drain and replace the fuel.
4. Charge the battery ([page 187](#)) as required. Install the battery.
5. Perform a pre-ride inspection ([page 55](#)), then test-ride your ATV at low speeds.