
## **Starting & Stopping the Engine**

## **Preparation**



- 1. Before starting, select a level surface and lock the parking brake (page 41).
- 2. Turn the ignition switch (1) to ON (q).