

B

bank angle sensor ignition cut-off system.....	62
battery.....	164
brakelight switch adjustment.....	151
brakes,	
cables.....	150
draining water from.....	152
fluid.....	142
front brake lever.....	31
pad wear.....	145
parking.....	32
rear brake lever.....	31
rear brake lever freeplay.....	148
rear brake pedal.....	31
rear brake pedal freeplay.....	146
shoe wear.....	150
braking.....	69
break-in guidelines.....	213
button, hourmeter/odometer/tripmeter select.....	13, 17, 20, 21, 22