


Controls & Features

Parking Brake

LEFT HANDLEBAR



- (1) lock lever (3) clutch lever/parking brake lever
(2) parking brake pin (A) to lock

The lock lever (1) and parking brake pin (2) on the clutch lever/parking brake lever (3) allows it to be used as a parking brake. To operate, push down and hold the parking brake pin, squeeze the clutch lever/parking brake lever and then lock it with the lock lever. See *Parking* [page 68](#).

To release the parking brake, squeeze the clutch lever/parking brake lever.