

Instruments & Controls

| | |
|---|----|
| Controls & Features | 35 |
| Ignition Switch..... | 35 |
| Range Select Lever..... | 36 |
| 4WD Switch | 37 |
| Front Differential Lock and Speed Limiter Over-Ride (Differential Lock Switch and Start/Over Ride Button)..... | 38 |
| Start/Over Ride Button | 41 |
| Engine Stop Switch..... | 42 |
| Headlight Switch | 43 |
| Headlight Dimmer Switch | 43 |
| Recoil Starter (Canada only)..... | 44 |
| Throttle Lever | 45 |
| Drive Mode Select Switch | 46 |
| Gearshift Switch | 47 |
| Front Brake Lever..... | 48 |
| Rear Brake Lever/Parking Brake Lever | 48 |
| Rear Brake Pedal..... | 48 |
| Parking Brake/Reverse Lever (P/R Lever)..... | 49 |
| Flag Pole Bracket | 51 |
| Trailer Hitch | 52 |
| Accessory Socket | 53 |
| Utility Box..... | 55 |
| Storage Compartment..... | 56 |
| PS (Electric Power Steering) (TRX500FA6/FA7)..... | 57 |