


# Controls & Features

---

## Range Select Lever

The range select lever (1) has two positions: Drive (D), Low (L). See *Shifting Gears*, page 95.

### LEFT SIDE OF FUEL TANK



(1) range select lever