

# Operation Component Locations

---

accessory socket

flag pole bracket

utility box

fuel valve

trailer hitch

storage compartment

