
## **Controls & Features**

## **Accessory Socket**

## LEFT FRONT



- (1) accessory socket
- (3) accessory socket cap
- (2) assist headlight

The accessory socket (1) is attached to the left side under the assist headlight (2). You can use the accessory socket to power a trouble light, spotlight, CB radio, or cell phone, etc.

## **NOTICE**

Do not plug in any heat-generating accessory, such as an automobile cigarette lighter, because it can damage the socket.

To use the accessory socket, turn the ignition switch ON (  $\mid$  ), start the engine. Then turn the headlights OFF (  $\bullet$  ), and open the accessory socket cap (3).