If you need to ride in reverse, make sure the area behind you is clear and only operate the ATV at low speed.

AWARNING

Improperly operating in reverse could cause you to hit an obstacle or person behind you, resulting in serious injury.

Make sure there are no obstacles or people behind you before selecting reverse gear. When it is safe to proceed, go slowly.

- 1. Bring the vehicle to a complete stop, then make sure the transmission is in neutral.
- 2. Depress and hold down the brake pedal.
- 3. Be sure there are no obstacles or people in the way.
- 4. While pushing the release button, shift the shift lever into "R" (reverse) gear.

If the vehicle won't shift easily into reverse, rock the vehicle slightly while moving the lever toward the reverse position. This will help line up the gears in the sub-transmission.

NOTICE

Your ATV may be equipped with a reverse speed limiter, which helps the vehicle to maintain a safe speed while riding in reverse gear.

NOTICE

If the shift lever is moved while the vehicle is moving, the subtransmission may be damaged.

(cont'd)