


Controls & Features

Shift Lever

The shift lever (1) has four positions: low (L), drive (D), neutral (N), and reverse (R).

See *Shifting Gears* ([page 76](#)) and *Riding in Reverse* ([page 83](#)).

LEFT SIDE OF FUEL TANK



(1) shift lever