


# Controls & Features

## Headlight Switch

y t

### LEFT HANDLEBAR



- |                             |       |
|-----------------------------|-------|
| (1) headlight switch        | y ON  |
|                             | t OFF |
| (2) headlight dimmer switch | u HI  |
|                             | i LO  |

The headlight switch (1) is used to turn the headlights and assist headlight ON (y ) or OFF (t). To operate, turn the switch to ON (y ) or OFF (t).

## Headlight Dimmer Switch

u i

The headlight dimmer switch (2) is used to change between the high and low beams of the headlight. To operate, turn the switch to HI (u ) for high beam, LO (i ) for low beam.

The headlight dimmer switch will not change the assist headlight beam.