

# Index

---

stalling on a hill .....	95
start/over ride button .....	39
starting,	
engine .....	78
troubleshooting .....	206
stop switch, engine .....	40
stopping engine .....	82
storage,	
ATV .....	198
owner's manual .....	119
suspension,	
adjustment .....	163
spring pre-load .....	164
switch,	
4WD .....	35
differential lock .....	36
engine stop .....	40
headlight .....	41
headlight dimmer .....	41
ignition .....	34

## T

tank cover assembly removal .....	122
throttle,	
cable .....	154, 155
lever .....	43, 154, 155
tires,	
air pressure .....	175
flat .....	209
repairing .....	179
replacing .....	180
thread conditions .....	177, 178
tool kit .....	118