

Quick Reference

These symbols are used in Controls & Features section:

SYMBOL	COMPONENT	SEE PAGE
I	ON — ignition switch	35
○	OFF — ignition switch	35
L D	range select lever	36
	4WD switch	37
	differential lock switch	39
	differential lock indicator — lights when the front differential lock mode engages	40
 OR	start/override button	41
	RUN — engine stop switch	42
	OFF — engine stop switch	42
	ON — headlight switch	43
•	OFF — headlight switch	43
	HI — headlight dimmer switch	43
	LO — headlight dimmer switch	43
AUTO	automatic shift mode — drive mode select switch	46
ESP	manual shift mode — drive mode select switch	46
	upshift switch — gearshift switch	47
	downshift switch — gearshift switch	47
PKB ↑	parking brake lock lever	50