
Controls & Features

Choke Lever d

LEFT SIDE



The choke lever (1) may be used when starting the engine. See page 56.