Removing & Installing Body Components In Seat

Installation

- 1. Insert the tabs into the recess under the frame.
- 2. Install and tighten the bolts C.
- 3. Install the rear seat.
- Install the collars B, washers, bolts B and seat strap to the rear seat. Tighten the bolts B.

Torque: 16 lbf·ft (22 N·m, 2.2 kgf·m)

- 5. Install the bolt A and collar A.
- 6. Tighten the bolts securely.
 - Be careful not to scratch the rear fender during seat installation or removal.
 - Be careful not to get the seat caught between the stay and bolts while installing the seat.