
## **Gauges, Indicators & Displays**

## Display Check

When the ignition switch is turned ON, the odometer/tripmeter/digital clock display (1) show all the modes and digital segments so you cam make sure the liquid crystal display is functioning properly.

The displays are identified in the table on page 17 with the words: *Display Check*.

If any part of these displays does not come on when it should, have your Honda dealer check for problems.



 odometer/tripmeter/digital clock display