

Servicing Your Honda

Service Preparations

Maintenance Component Locations	71
Tool Kit.....	74
Owner's Manual Storage.....	75
Side Cover Removal.....	76
Seat Removal.....	77

Service Procedures

Fluids & Filters

Fuel	78
Engine Oil & Filter.....	81
Coolant.....	91
Air Cleaner	95
Crankcase Breather	97
Final Drive Oil.....	98

Engine

Throttle	101
Clutch System.....	103
Spark Plugs.....	107

Chassis

Suspension.....	110
Brakes	113
Tires	121
Side Stand.....	129

Electrical

Battery	130
Appearance Care	135