

## Gauges, Indicators & Displays

1	speedometer	Shows riding speed in miles (USA) or kilometers (Canada) per hour.
2	fuel reserve indicator (amber)	When this indicator comes on while riding, fuel reserved in the tank is about: <b>0.92 US gal (3.5 l)</b>
3	turn signal indicator (green)	Flashes when either turn signal operates.
4	high beam indicator (blue)	Lights when the headlight is on high beam.
5	Anti-lock Brake System (ABS) indicator (amber) (VT750C ABS)	Lights when there is any abnormality in the Anti-lock Brake System (ABS). Normally, this indicator comes on when the ignition switch is turned ON, and goes off after you ride the motorcycle at a speed above 6 mph (10 km/h). If the indicator comes on while riding, stop the motorcycle in a safe place and turn off the engine. Refer to <i>Anti-lock Brake System (ABS) Indicator</i> , page 47. For information about Anti-lock Brake System (ABS), see page 46. <i>Lamp Check</i> .