


## Gauges, Indicators & Displays

---

5. Push and hold the select/reset button for more than 2 seconds. The minute display will start flashing.
6. To set the minute, push the select/reset button until the desired minute is displayed. The minute display will return to “00” when “60” is reached without affecting the hour display.



7. To end the adjustment, push and hold the select/reset button for more than 2 seconds or turn the ignition switch OFF. The display will stop flashing automatically and will exit the adjustment mode if the button is not pressed for about 30 seconds.