

Servicing Your Honda

Service Preparations

Maintenance Component Locations	69
Tool Kit.....	72
Owner's Manual Storage.....	73
Storage Compartment.....	74
Side Cover Removal.....	75
Seat Removal.....	76

Service Procedures

Fluids & Filters

Fuel	77
Engine Oil & Filter.....	80
Coolant.....	90
Air Cleaner	94
Crankcase Breather	96
Final Drive Oil.....	97

Engine

Throttle	100
Clutch System.....	102
Spark Plugs	106

Chassis

Suspension	109
Brakes	112
Tires	121
Side Stand.....	129

Electrical

Battery	130
---------------	-----

Appearance Care	135
-----------------------	-----