

manuals	206
warranty	210
shifting gears	41
side cover removal.....	75
side stand	129
side stand ignition cut-off system.....	37
spark knock.....	77
spark plugs	106
specifications	185
speedometer.....	13, 15
stand, side	129
start button	22
starting,	
engine.....	37
troubleshooting.....	149
steering lock.....	49
stop switch, engine	22
stopping engine.....	40
storage,	
compartment.....	74

motorcycle	142
owner's manual	73
suspension,	
rear suspension adjustment	110
rear suspension spring pre-load.....	110
switch,	
engine stop.....	22
headlight dimmer.....	23
ignition	21
turn signal	23

T

theft-prevention tips	51
throttle.....	100

(cont'd)