

# Refueling

**Fuel type:** Unleaded gasoline only

**Recommended fuel octane number:** Your scooter is designed to use Pump Octane Number (PON) 86 or higher.

**Tank capacity:** 2.11 US gal (8.0 liters)

## Refueling and Fuel Guidelines ( P13)

### Opening the Fuel Fill Cap

- a Insert the ignition key and turn it to the position of SEAT FUEL.
- b Push the FUEL side of the fuel lid and seat opener switch.
  - u The fuel lid opens.

