
Switches (Continued) Steering Lock

Lock the steering when parking to help prevent theft.

An U-shaped wheel lock or similar device is also recommended.



Locking

- Turn the handlebar all the way to the left (or right only when the center stand is used).
- 2 Push the key down, and turn the ignition switch to the ਜ਼ (Lock) position.
 - ► Jiggle the handlebar if the lock is difficult to engage.
- **3** Remove the key.

Unlocking

Insert the key, push it in, and turn the ignition switch to the OFF position.