

Adjusting the Headlight Aim

You can adjust vertical aim of the headlight for proper alignment. Turn the screw using a Phillips screwdriver provided in the tool kit (▶ P. 52) in or out as necessary. Obey local laws and regulations.

