


# Refueling



Do not fill with fuel above the filler neck.

**Fuel type:** Unleaded gasoline only

**Recommended fuel octane number:**

Pump Octane Number (PON) 86 or higher.

**Tank capacity:** 2.77 US gal (10.5 liters)

**Reserve capacity:** 0.61 US gal (2.3 liters)

**Refueling and Fuel Guidelines** ➔ P. 12

## Opening the Fuel Fill Cap

- 1 Open the lock cover, insert the ignition key, and turn it clockwise.

- 2 Turn the fuel fill cap counterclockwise and remove it.

## Closing the Fuel Fill Cap

- 1 Install and tighten the fuel fill cap firmly by turning it clockwise until the arrow mark on the cap faces forward.
- 2 Turn the ignition key counterclockwise.
- 3 Remove the ignition key from the cap.

## **⚠️ WARNING**

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.