





Switches

Headlight dimmer switch

-  : High beam
-  : Low beam

Engine stop switch

Should normally remain in the RUN  position.

- ▶ In an emergency, switch to the off  position to stop the engine.

Start button

Headlight turns off when operating the starter motor.



Turn signal switch

- ▶ Pressing the switch turns the turn signal off.



Horn button

