


Instruments

Gear range indicator

Shows proper speed range for each gear.

Speedometer

This shows your speed in miles per hour.



Tripmeter reset knob



Odometer

Total distance ridden.
Odometer and Tripmeter read in miles.

Tripmeter

Distance ridden since you last reset the meter. (Turn the tripmeter reset knob as shown to reset to zero (0)).