


### Inspecting Tread Depth

Inspect the tread wear indicators. If they become visible, replace the tyres immediately.

**CFT125MR/MS**

For safe riding, you should replace the tyres when the minimum tread depth is reached.



## ⚠ WARNING

Riding on tyres that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tyre inflation and maintenance.