
## **Storage Equipment** (Continued) Helmet holder

The helmet holder is on the left side below the seat.

A helmet set wire is in the tool kit. P.29



## Unlocking

Open the lock cover, insert the ignition key and turn it clockwise.

## Locking

- 1 Hang both ends of the helmet set wire that has been passed through the helmet D-ring on the holder pin and push it in to lock.
- 2 Remove the key and close the lock cover.
  - Use the helmet holder only when parked.

## AWARNING

Riding with a helmet attached to the holder can interfere with the rear wheel or suspension and could cause a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.