


- E-1
- E-2
- E-3

CYLINDER HEAD COVER / INLET PIPE
 CYLINDER/ CYLINDER HEAD
 CAM SHAFT/VALVE

1
 3
 4



- E-4
- E-5
- E-6
- E-7A-SELF
- E-7B-SELF
- E-7C-SELF


CAM CHAIN TENSIONER
 RIGHT CRANKCASE COVER
 CLUTCH
 LEFT CRANKCASE COVER/A.C. GEN. ASSY.
 STARTING CLUTCH
 STARTING MOTOR

5
 6
 7
 9
 11
 12

- E-7-KICK
- E-8-KICK
- E-8-SELF

LEFT CRANKCASE COVER/A.C. GEN. ASSY.
 CRANK CASE/ OIL PUMP
 CRANK CASE/ OIL PUMP

13
 15
 17



- E-9
- E-10
- E-11
- E-12
- E-13

CRANK SHAFT/ PISTON
 TRANSMISSION
 KICK STARTER
 GEAR SHIFT
 CARBURETTOR

19
 21
 23
 24
 26