


F-1 Cable • Switch • Handle grip

D 5

F-1 Cable • Switch • Handle grip



Ref. No.	Part No.	Description	Reqd. No. CB125K5	Serial No.	Area code
1	17910-304-610	CABLE COMP., THROTTLE	1		F,G
	17910-342-000	CABLE COMP., THROTTLE	1		DK,DM,ED
2	22870-304-610	CABLE COMP., CLUTCH	1		F,G
	22870-336-000	CABLE COMP., CLUTCH	1		DK,DM,ED
3	35250-300-033	SWITCH ASSY., WINKER HORN (TOYO)	1	5040704	DK,DA,F,G
			1		ED
	35250-315-003	SWITCH ASSY., WINKER HORN (TOYO)	1	5040705	DK,DM,F,G
4	35300-316-670	SWITCH ASSY., STARTER LIGHTING	1		DK,DK
	35300-336-610	SWITCH ASSY., DIMMER	1		G
	35300-342-600	SWITCH ASSY., STARTER LIGHTING & KILL	1		ED,F
5	35315-235-000	KNOB, LIGHTING SWITCH	1		
6	35317-001-310	BUTTON, HORN SWITCH PUSH	2		
7	35317-235-000	BUTTON, HORN SWITCH PUSH	1		
	35317-310-810	KNOB, WINKER SWITCH	1		
8	35318-259-000	SPRING, HORN PUSH BUTTON	2		
9	35340-320-670	SWITCH ASSY., FR. STOP	1		
10	45450-235-010	CABLE COMP., FR. BRAKE	1	5021590	DK,DM,ED
	45450-351-000	CABLE COMP., FR. BRAKE	1	5021591	DK,DM,ED
	45450-304-611	CABLE COMP., FR. BRAKE	1		F,G
11	45465-270-000	CLIP, FR. BRAKE CABLE	1		DK,DM,ED
12	53165-283-000	RUBBER, R. GRIP	1		
13	53166-283-000	RUBBER, L. GRIP	1		
14	53170-286-670	LEVER COMP., R. STEERING HANDLE	1	5041104	
	53170-369-700	LEVER COMP., R. STEERING HANDLE	1	5041105	DK,DM,ED,G
			1	5041105	F
	53175-369-700	LEVER, R. STEERING HANDLE	1		F
15	53180-286-000	CAP, CONTROL LEVER	2	5041104	

B315-21A